

Tuff Tread

502 W. Montgomery STE 120
Willis, TX 77378
PH: (800)827-2017 FAX: (888)898-8974
www.TuffTread.com

Display Board Version Test

This procedure will determine which display board version has been installed in the Noramco Fitness, Super Tuff, or Tuff Tread Treadmill. Before attempting to recalibrate the display board, use the following procedure to determine which display version is installed in the treadmill.

- ❑ With the treadmill plugged in and idle, remove the emergency stop magnet and replace it while watching the “Speed” window in the lower left part of the display.
- ❑ If the “Speed” window lights up with a number - .4, .5, .6 or .7 – the display is a version 1.4, 1.5, 1.6 or 1.7 respectively. The calibration instructions are the same for all the 1.4, 1.5, 1.6, and 1.7 board versions.
- ❑ The numbers 19.2 or 19.3 in the “Speed” window indicate display versions 1.92 and 1.93 respectively. The calibration instructions are the same for 1.92 or 1.93 boards.
- ❑ If there is no number in the “Speed” window when the magnet is placed on the display, look at the “Time” window at an angle from below. There will be two LEDs lit behind and slightly above the “Time” window. This indicates a version 2 display.
- ❑ Version 3.0, 4.0, and version 5.0 displays will light up with the series number – 4600 – in the “Time” window, and the program level – C, CC, PR, PRC, or HRT – in the “Calorie” window. The “Speed” window on the lower left will display the complete display software version number.